

## Dual digital display type fiber optic amplifiers

### ■ Features

- **Dual-display for light incident level and setting value(BF5□-D)**
- **Minute object sensing available with 1/10,000 high resolution**
- Enables to detect with high-speed(20,000 times per sec.) moving objects
- 4 response speeds
  - : Ultra fast mode(50μs), high speed mode(150μs), standard mode(500μs), long distance mode(4ms)
- Long lasting amplifier regardless of element's life degradation or temperature change
- Multiple sensitivity setting modes available
  - : auto tuning, 1 point(maximum sensitivity), 2 point, positioning teaching
- Up to 8 units enable to stack with mutual interference prevention function using side connectors
- Auto channel setting function for multiple installations
- Slim design(W10×H30×L70mm)

PNP output model

Line-up



**⚠ Please read "Caution for your safety" in operation manual before using.**



### ■ Specifications

Display type	Dual Display type			Single Display type	
Model	NPN open collector output	BF5R-D1-N	BF5G-D1-N	BF5B-D1-N	BF5S-S1-N
	PNP open collector output	BF5R-D1-P	BF5G-D1-P	BF5B-D1-P	BF5S-S1-P
Light source	Red LED (660nm, modulated)	Green LED (530nm, modulated)	Blue LED (470nm, modulated)	Red LED (660nm, modulated)	
Power supply	12-24VDC±10%				
Current consumption	Max. 50mA				
Operation mode	Light ON / Dark ON Selectable				
Control output	NPN or PNP open collector ●Load voltage: Max. 24VDC ●Load current: Max. 100mA ●Residual voltage - NPN:Max. 1V, PNP:Max. 3V				
Protection circuit	Reverse polarity protection, overcurrent protection, surge absorption				
Response time	Ultra Fast : 50μs(only for dual display type), Fast : 150μs,STD : 500μs, Long : 4ms				
Display method	●Incident light level: Red, 4digit, 7Segment ●SV : Green, 4digit, 7Segment ●Main output indicator : Red LED			●Incident light level / SV : Red, 4digit, 7Segment ●Main output indicator : Red LED	
Display function	Incident light level / SV display [4,000/10,000 resolution], Percentage display, High/Low peak value display, Normal / Reversed display (only for dual display type)				
Sensitivity setting	Manual sensitivity setting, teaching sensitivity setting (Auto tuning, 1 point, 2 point teaching, positioning teaching)			Manual sensitivity setting, teaching sensitivity setting (auto tuning)	
Mutual interference prevention	Max. 8 unit sets (Automatically set regardless of response time)				
Initializing	Initializing to factory mode			—	
Energy saving	Normal / Energy saving 1 / Energy saving 2			—	
Timer	OFF, OFF Delay, ON Delay, One-shot			OFF, 10ms OFF Delay timer, 40ms OFF Delay timer	
Insulation resistance	Min. 20MΩ(at 500VDC megger)				
Dielectric strength	1,000VAC 50/60Hz for 1 min.				
Vibration	1.5mm amplitude or 300m/s <sup>2</sup> at frequency of 10 to 55Hz(for 1 min.) in each X, Y, Z directions for 2 hours				
Shock	500m/s <sup>2</sup> (approx. 50G) in each X, Y, Z directions for 3 times				
Environment	Ambient illumination	Incandescent lamp : Max. 3000lx Sunlight : Max. 11000lx (received illumination)			
	Ambient temperature	-10 to 50°C, storage: -20 to 70°C			
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH			
Protection	IP40(IEC standards)				
Material	Case : PBT, Cover : PC				
Fiber cable Tightening torque	Min. 2kgf				
Accessory	Connector type wire(Ø4, 3-wire, length: 2m) (AWG22, Core diameter: 0.08mm, Number of cores: 60, Insulator out diameter: Ø1.25), Side connector				
Approval	CE				
Unit weight	Approx. 20g				


※The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

(A)	Photo electric sensor
(B)	Fiber optic sensor
(C)	Door/Area sensor
(D)	Proximity sensor
(E)	Pressure sensor
(F)	Rotary encoder
(G)	Connector/ Socket
(H)	Temp. controller
(I)	SSR/ Power controller
(J)	Counter
(K)	Timer
(L)	Panel meter
(M)	Tacho/ Speed/ Pulse meter
(N)	Display unit
(O)	Sensor controller
(P)	Switching mode power supply
(Q)	Stepper motor& Driver&Controller
(R)	Graphic/ Logic panel
(S)	Field network device
(T)	Software
(U)	Other


# BF5 Series

## Control output diagram

### • NPN open collector output



### • PNP open collector output




## Dimensions

(unit: mm)

### • BF5□-D1-□




### • BF5R-S1-□




### • Accessories

- Connector type wire (length: 2m)



- Side connector




## Installations

### Ⓞ Amplifier unit mounting

- Installation: Hang up the backside holder on the DIN rail and press the unit toward the DIN rail.
- Removal: Slide the back part of the unit as the ① figure and lift up the unit as the ② figure.

### Ⓞ Amplifier unit connection

- Remove the side cover at the connecting side as the figure ① and connect the side connector as the figure ②.
  - After mounting the unit on the DIN rail, push gently both units to fasten each other.
- ※ Make sure that connections between the unit case and connectors correctly. Improper connection may cause malfunction of channel setting and mutual interference prevention functions.
- ※ Do not supply the power while connecting / disconnecting amplifier units.




# Fiber Optic Amplifier

## ◎ Fiber cable connection

- Lift up the protective cover ① and push down the lock lever to the direction of ② to release the lock setting.
- Insert the cable to the direction of ③ with slightly moving up and down 15°, and gently press into the unit until the cable is completely inserted (inserted length: around 13mm).
- Lift up the lock lever to lock the lock setting ④ and close the protective cover to ⑤.

## ◎ Wire connector connection

- Insert the connector into the amplifier unit until it clicks into right position.
- When removing the connector, pull out the connector to the ① direction with pressing the lever downside to the ② direction.




## ■ Part descriptions

### ● BF5□-D1-□



- 1. Control output indicator(Red)**  
: Used to indicate control output provided by comparing SV and actual incident light level
- 2. Sensitivity setting key**  
: Used to execute each operation and to set sensing sensitivity
- 3. PV display part (4 Digit, Red, 7 segments)**  
: Used to indicate incident light level and parameters
- 4. SV display part (4 Digit, Green, 7 segments)**  
: Used to indicate SV and setting data
- 5. Up/down key**
  - Used to up/down setting values
  - Used to Fine-adjusting sensitivity
- 6. MODE key**
  - Used to enter into program mode / data Bank mode
  - Used to move each parameter


### ● BF5R-S1-□



- 7. PV/SV display part(4 Digit, Red, 7 segments)**  
: Used to indicate incident light level / SV and parameters
- 8. Response time setting switch** : FAST, STD, LONG
- 9. Timer setting switch**  
: Used to select OFF Delay time (OFF, 10ms, 40ms)
- 10. Operation mode setting switch**  
: Used to select Light ON / Dark ON
- 11. Up/Down key**
  - Used to up/down setting values
  - Used to enter into each mode
  - Used to Fine-adjusting sensitivity
- 12. Lock lever**

## ■ Parameter setting

### ● BF5□-D1-□



(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/Socket

(H) Temp. controller

(I) SSR/Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/Speed/Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching mode power supply

(Q) Stepper motor& Driver&Controller

(R) Graphic/Logic panel


(S) Field network device

(T) Software

(U) Other

# BF5 Series

## • BF5R-S1-□



## Dual display type (※Refer to B-12 to 20 page.)

### ■ Sensitivity setting mode

※There are two methods available for sensitivity setting - manual/teaching sensitivity setting. Select the method most suitable for your application.

#### ◎ Manual sensitivity setting (Fine-adjusting sensitivity)

- The setting is to set the sensitivity manually.
- Used to fine-adjusting sensitivity after the teaching sensitivity setting.
- Incident light level is still displayed on the PV display part during setting.



- ① Press the left and right keys to set the value.
- ② There is no additional key for completing the setting. If there is no key input for 3 sec. after completing setting, last set value flashes twice (every 0.5 sec) and automatically saved it and returned to RUN mode.

#### ◎ Teaching sensitivity setting (Auto-tuning, One-point, Two-point, Positioning)



- How to enter into sensitivity setting mode in RUN mode  
Press the [SET] key once and the selected teaching mode parameter flashes twice on the SV display part.
- ※Refer to [B-12 to 14] pages for each teaching sensitivity setting.
- Teaching should be executed for over 3 sec.
- ※If teach mode is executed for less than 3 sec., teach mode parameter flashes twice and be on standby to execute completion of teach mode.
- Current incident light level is indicated on PV display part while teaching is in the process.
- If incident light level is received under 10 digit while teaching is in the process, it is automatically returned to RUN mode and previous setting value is retained after *ERR L* flashes twice.
- ※If there is no key operation for 60 sec after entering into teaching mode, it is automatically return to RUN mode.

##### 1) Auto-tune teach mode

※Suitable when incident level of sensing object is not stable or when sensing fast moving objects.  
※Auto-tune automatically sets the sensitivity using the average value of the incident light level within a certain time period.

$$\text{Set\_value} = \frac{P1+P2+ \dots +Pn-1+Pn}{n}$$



- Set Teaching mode parameter[ *SEN5* ] to *AUTO*.



## 2) One-point teach mode

※One of teaching modes that sets the maximum sensitivity by teaching one sensitivity setting point when setting the SV with no sensing object (Reflective) or when setting the SV with incident light level 0(Through-beam) / Suitable for the applications required little effect of dust or background.

- Set Teaching mode parameter [5E<sub>n</sub>5] to 1P<sub>nt</sub>.



※SV range for sensing distance.



Response Time	Teaching when incident light level is 0	Teaching when incident light level is saturated
UF5t	In case incident light level is 0, set to 10 digit.	In case incident light level is saturated, set to 3980 digit.
F5t		
5td	In case incident light level is 0, set to 5 digit.	In case incident light level is saturated, set to 9980 digit.
L0G		

## 3) Two-point teach mode

※Suitable when incident light level is stable or when sensing object is slow or at stopped position.

※One of teaching modes that sets the sensitivity using average value of two incident light levels obtained from two point teaching - one point with a sensing object and the other point without a sensing object.

- Set Teaching mode parameter [5E<sub>n</sub>5] to 2P<sub>nt</sub>.





※Make sure that two point teaching must be done within 60 sec after one point teaching. If not, teaching mode is cancelled and it returns to RUN mode.

- (A) Photo electric sensor
- (B) Fiber optic sensor
- (C) Door/Area sensor
- (D) Proximity sensor
- (E) Pressure sensor
- (F) Rotary encoder
- (G) Connector/ Socket
- (H) Temp. controller
- (I) SSR/ Power controller
- (J) Counter
- (K) Timer
- (L) Panel meter
- (M) Tacho/ Speed/ Pulse meter
- (N) Display unit
- (O) Sensor controller
- (P) Switching mode power supply
- (Q) Stepper motor& Driver&Controller
- (R) Graphic/ Logic panel
- (S) Field network device
- (T) Software
- (U) Other

## 4) Positioning teach mode


※One of teaching modes that sets the sensitivity to 90% of max. incident light level when sensing an object with a hole on the surface (Through-beam) or sensing a moving object having curve (Reflective).

- Set Teaching mode parameter [SEn5] to P5En.




## ■ Group teach mode


A function to set the sensitivity of Slave amplifier units according to the command of Master amplifier unit (a certain amplifier unit) in a successive and collective way.



※1: Display part status while teaching is in the process




## Master / Slave unit display during group teach mode



## Program mode setting

- When entering into program mode, parameters lights ON on the PV display part and setting values flashes every 0.5 sec. on SV display part. Use the  $\leftarrow$ ,  $\rightarrow$  keys to set each setting value.
- Press the **MODE** key one time after setting each parameter to save each setting and enter into next mode.
- If the key lock is set, unlock the key lock before setting parameters.

### Program mode flow



(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/Socket

(H) Temp. controller

(I) SSR/Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/Speed/Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching mode power supply


(Q) Stepper motor& Driver&Controller

(R) Graphic/Logic panel

(S) Field network device

(T) Software

(U) Other



## ■ Program mode function

### ◎ Response time setting [r5Pd]

A function to set the response time of control output - 4 response modes selectable.

- Ultra Fast [UF5t] mode : 50μs
- Fast [F5t] mode : 150μs
- Standard [5td] mode : 500μs
- Long distance [LonG] mode : 4 ms

### ◎ Display function [d5PF]

A function to select incident light level display mode on PV display window: Standard display [4000] / Percentage display [999P]

- Display range of standard mode : 0 to 4000 (0 to 9999, in case of long distance mode)
- Display range of percentage mode : 0P to 99.9P (Decimal point is not displayed)

### ◎ Display direction setting function [dlr]

A function to reverse the display direction to suit the unit installation location: Normal display / Reversed display selectable.


※ Reversed display is upside-down(180°) display of normal display.

### ◎ Timer function [Timer operation mode: tnod, Time setting: t1nE]

Used when external device's response time is too late or when control output time is too short due to small sensing object - 3 modes are available.

- Timer Off [oFF]
- On Delay [ond] : Delays control output ON time from OFF for a certain period of setting time
- Off Delay [oFd] : Delays control output OFF time from ON for a certain period of setting time
- One-shot [SHot] : Turns control output ON or OFF within a certain period of setting time
- Setting time [t1nE] : 1 to 5000ms

#### ● Time chart



※ Setting time :  $T > T_a$ ,  $T > T_b$ ,  $T > T_c > T_b$



## ◎ Energy saving function [E5A] ]

A function to save unit's power consumption by reducing power supply to display parts in case of no setting input within 60 sec.

- Selectable from 2 power saving modes
- Normal mode [n o r ] : Main output indicator(OUT), PV/SV display part ON
- Energy saving mode 1 [ 15A ] : Main output indicator(OUT) and PV display part ON
- Energy saving mode 2 [25A ] : Main output indicator(OUT) ON

## ◎ Light ON / Dark ON switching function [L d o n ]

A function to set Light ON - control output is ON when incident light level is higher than setting value Dark ON - control output is ON when incident light level is lower than setting value.

## ◎ Communication enable / disable setting function [C o n n ]

A function to set communication write [enable( E n A ) / disable(d i 5A )] for Slave amplifier units while certain instructions (Load/Save/Copy) or Group teaching is in progress by the Master amplifier unit.

## ◎ Lock function [L o c k ]

Two types of key lock setting are available in order to prevent SV changes due to careless.

	o f f	L o c 1	L o c 2
Sensitivity setting	●	◐	◐
Data Bank mode	●	○	○
Program mode	●	◐	○
Parameter initialization	●	○	○

- ※● : Check / Setting both available  
 ◐ : Check available  
 ○ : Check / Setting both unavailable

- In case of [L o c 2] mode, it is required to disable the lock function first to enter into parameter mode.

## ■ Data Bank setting

A function to save settings for group amplifier units in each data Bank by using Master unit's command or by adjusting one amplifier unit's setting and to load required data Bank when it is necessary without resetting for each unit's parameters and setting values.

- LOAD [L o a d ] : Loads preset dataBank(b A B 0 , 1 , 2) and applies it to the amplifier unit.  
Detailed Bank parameters can be read and changed.
  - SAVE [5 A v E ] : Saves one amplifier unit settings in one of dataBank(b A B 0 , 1 , 2).
  - COPY [C o p y ] : Copies the currently loaded Bank by Master's instructions to the other amplifier unit (1:1) or the whole amplifier units (1: M).
  - LOAD ALL [L o a l l ] : Selects one dataBank by Master's instructions loads it to entire group units.
  - SAVE ALL [5 a r l ] : Selects one dataBank by Master's instructions and saves it in entire group units.
- ※For BF5□-D1-□, three dataBanks are available ([b A B 0], [b A B 1] and [b A B 2]) so that three different sensing object information can be saved. Each Bank can be read and changed. It allows users to detect three different sensing objects with one amplifier unit without resetting each parameter.
- ※DataBank function can be executed only if all amplifier units are in RUN mode.
- ※Copy/Load All/Save All functions are applicable only if multiple amplifier units are connected.
- ※If lock function is set(L o c 1 / L o c 2) on amplifier units or if the Slave unit is set to communication disable[d i 5A], Load and Save command for the unit does not execute.

(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/Socket

(H) Temp. controller

(I) SSR/ Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/ Speed/ Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching mode power supply

(Q) Stepper motor& Driver&Controller

(R) Graphic/ Logic panel


(S) Field network device

(T) Software

(U) Other


# BF5 Series

## ◎ Data Bank mode flow




## ◎ Master / Slave unit display during data Bank setting

### ● Copy All




- ① While Copy All is executed, the Master unit displays the channel number on the PV display part and 0E on the SV display part.
- ② While Copy All is executed, the Slave units display 70 on the PV display part and 0E on the SV display part and they return to RUN mode.
- ③ When Copy All is completed, the Master unit displays COPY on the PV display part and End on the SV display part. Press the SET key to return to Data Copy mode. ※In case of 1:1 Copy, it progresses as same.

### ● Load All



- ① While Load All is executed, the Master unit displays the channel number on the PV display part and 0E on the SV display part.
- ② While Load All is executed, the Slave units display LDR on the PV display part and End on the SV display part and they return to RUN mode.
- ③ When Load All is completed, the Master unit displays LDR on the PV display part and End on the SV display part. Press the SET key to return to Load All mode.

### ● Save All



- ① While Save All is executed, the Master unit displays the channel number on the PV display part and 0E on the SV display part.
- ② While Save All is executed, the Slave units display SAR on the PV display part and End on the SV display part and they return to RUN mode.
- ③ When Save All is completed, the Master unit displays SAR on the PV display part and End on the SV display part. Press the SET key to return to Save All mode.


※If communication write enable / disable parameter [C0nn] for the Slave unit is set to disable dI 5R while Save All, Load All or Copy is executed, the master unit displays channel number on the PV display part and dI 5R on the SV display part.

(A)	Photo electric sensor
(B)	Fiber optic sensor
(C)	Door/Area sensor
(D)	Proximity sensor
(E)	Pressure sensor
(F)	Rotary encoder
(G)	Connector/Socket
(H)	Temp. controller
(I)	SSR/Power controller
(J)	Counter
(K)	Timer
(L)	Panel meter
(M)	Tacho/Speed/Pulse meter
(N)	Display unit
(O)	Sensor controller
(P)	Switching mode power supply
(Q)	Stepper motor& Driver&Controller
(R)	Graphic/Logic panel
(S)	Field network device
(T)	Software
(U)	Other

# BF5 Series

## High peak, Low peak function

A function to monitor the high/low peak value of incident light level. The monitored high/low peak value can be initialized.



- ① Press the **MODE** key for a sec to monitor max/min incident light level.
- ② Press the **MODE** key to initialize max/min value to current incident light level during monitoring.
- ③ Press the **MODE** key to return to RUN mode.


## Initializing function

A function to initialize all parameters in memory to default value in case the possibility of mis-setting or mis-operation.

※Set lock function [**L o C k**] to **o F F** to execute Initializing Function.

※High peak value[HPEL] and low peak value[LPEL] shall not be initialized.

### Parameter initialize flow



- ① Press the **MODE** key for 7 sec. in RUN mode. *i n i t* parameter turns ON on PV display part and *n o* flashes every 0.5sec. on SV display part.
- ② Press the **MODE** key once again to return to RUN mode without executing initializing Function.
- ③ Select **y e s** using the **◀**, **▶** keys and press the **SET** key. *i n i t* flashes twice on both PV and SV display parts.
- ④ When parameter initialization is completed, it is automatically returned to RUN mode.

### Parameter value for initialization (factory default)

Parameter	Factory default	Parameter	Factory default	Parameter	Factory default
rSPd	5td	tñod	oFF	Ldon	L-on
dSPF	4000	SEnS	RUto	Loññ	EnR
dI r	1234	ESRu	nor	LoCk	oFF

SV : 2000, Bank 0 to 2 : Initialized

## Single display type (※Refer to B-20 to 22 page.)


## Sensitivity setting mode

※There are two methods available for sensitivity setting - manual or teach mode.

Select the method most suitable for your application.

### Manual sensitivity setting (Fine-adjusting sensitivity)

- The setting is to set the sensitivity manually.
- Used to fine-adjust sensitivity after the teaching sensitivity setting.
- Incident light level is still displayed on the PV/SV display part during SV setting.





- ① Press the **◀** or **▶** key once in RUN mode, then previous SV flashes twice(every 0.5 sec.).
- ② Press the **◀** and **▶** keys to set the value.
- ③ There is no additional key for completing the setting. If there is no key input for 3 sec after completing setting, newly set value flashes twice (every 0.5 sec) and automatically save it and returned to RUN mode.

## Teaching sensitivity setting(Auto tuning teaching)

- For BF5R-S1-□ model, teaching sensitivity setting mode is fixed to auto-tuning.
- ※This mode is easy the sensitivity when incident light level of sensing object is not stable or moved fast.
- ※One of teaching modes that sets the sensitivity using average value of the maximum and minimum incident light level within a certain time period.

$$\text{Set\_value} = \frac{P1+P2+ \dots +Pn-1+Pn}{n}$$

- In program mode, set Teaching mode parameter [5E75] to AUTO.



- If incident light level is received under 10 digit while teaching is in the process, ERR flashes twice and it returns to RUN mode with the previous SV retained.

- ※1: After flashing AUTO twice, press the [D] key to return to RUN mode without teaching.
- ※2: Press the [SET] key over 3 sec in order to get more reliable teaching value.

## Function

### Response time setting

Use front slide switch to set response time.


- Fast(FAST) mode : 150μs
- Standard(STD) mode : 500μs
- Long distance(LONG) mode : 4ms

### Display function (Factory mode: standard display)


A function to select incident light level display on display part.

- Display range of standard mode : 0 to 4000 (0 to 9999, in case of long distance mode)
- Display range of percentage mode : 0P to 99.9P (Decimal point in not displayed)

<When changing to standard display mode>




<When changing to percentage display mode>



### Timer function

- ※For the BF5R-S1-□ model(single display type), only OFF Delay mode is available. Select the setting time (OFF/10ms/40ms) using the front slide switch.

#### Time chart



(A)	Photo electric sensor
(B)	Fiber optic sensor
(C)	Door/Area sensor
(D)	Proximity sensor
(E)	Pressure sensor
(F)	Rotary encoder
(G)	Connector/Socket
(H)	Temp. controller
(I)	SSR/ Power controller
(J)	Counter
(K)	Timer
(L)	Panel meter
(M)	Tacho/ Speed/ Pulse meter
(N)	Display unit
(O)	Sensor controller
(P)	Switching mode power supply
(Q)	Stepper motor& Driver&Controller
(R)	Graphic/ Logic panel
(S)	Field network device
(T)	Software
(U)	Other

# BF5 Series


## ◎ Light ON / Dark ON switching function

A function to set Light ON - control output is ON when incident light level is higher than setting value and Dark ON - control output is ON when incident light level is lower than setting value.


BF5R-S1- □ (Single display type) model uses the front slide switch to set each mode.

## ■ Group teaching

A function to set the sensitivity of Slave amplifier units according to the command of Master amplifier unit(a certain amplifier unit) in a successive and collective way.




※1: Display part status while teaching is in the process



## High peak, low peak function

A function to monitor the high/low peak value of incident light level. The monitored high/low peak value can be initialized.



(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure sensor

(F) Rotary encoder

(G) Connector/Socket

(H) Temp. controller

(I) SSR/Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/Speed/Pulse meter

(N) Display unit

(O) Sensor controller

(P) Switching mode power supply

(Q) Stepper motor& Driver&Controller

(R) Graphic/Logic panel

(S) Field network device

(T) Software

(U) Other

## Dual display / Single display common features

## Program mode function

### Amplifier units connection using side connector

In case multiple amplifier units are connected, the power supply for one unit will feed all connected units.

### Auto channel setting function

- The channel for each amplifier unit - connected by side connector - is automatically set in a certain direction ( → ) as soon as power is supplied. Channel number is increasing one by one.
  - Auto set channel can be checked in channel parameter in program mode.
  - In case of BF5R-S1- □, auto set channel can be checked only when initial power is supplied. (Not available afterwards).
  - Channel range : 1 to 32(applied the same to all models)
- ⊗ **Note that auto set channel cannot be changed and the channel No. of each amplifier unit is not saved in case of power OFF.**

### Mutual interference prevention function

A function to set different light receiving time for each amplifier unit in case of adjacent fiber cable installations in order to prevent mutual interference occurring. (Set automatically when power is turned ON.)

⊗ Mutual interference function is allowed up to maximum 8 amplifier units regardless of the unit model and response time.

## Error code

Error code	Cause	Troubleshooting
<i>ErrL</i>	In case incident light level is below the min. range when teaching.	Increase the incident light level above min. range.
<i>Err</i>	In case overcurrent inflow occurs into output circuit.	Remove overcurrent due to overload.
<i>Errb</i>	<ul style="list-style-type: none"> <li>• In case Slave is failed to execute Master's instructions due to unstable communication line connection during Group Copy / Load / Save / Teaching.</li> <li>• In case other communication errors occur</li> </ul>	<ul style="list-style-type: none"> <li>• Check amplifier unit's connection again.</li> <li>• Check circuit and hardware around side connector.</li> </ul>